



## Module M1-2 Review Quiz

1. The default direction for angles is counterclockwise

- a. True.
- b. False.

2. How do you adjust the view to display the entire drawing in the drawing window?

- a. Double-click the right mouse button.
- b. Hold <Ctrl> and scroll the mouse wheel.
- c. Double-click the mouse wheel.
- d. Hold the mouse wheel and drag the cursor.

3. How are coordinates defined in the AutoCAD Cartesian workspace?

- a. X value, Y value
- b. Y value, X value
- c. X value followed by Y value
- d. X value minus Y value

4. When using the Line command, once you've finished drawing your line segments, how do you exit the command?

- a. Press the Escape key.
- b. Choose END from either the Command Line or the Dynamic Input pulldown menu.
- c. Press either the Enter key or the Spacebar on the keyboard.
- d. Double-click the scroll wheel on the mouse.

5. When using Dynamic Input, how do you switch between entry fields?

- a. Click on the field using your mouse.
- b. Press the Tab key on your keyboard to move between fields.
- c. Press <Shift>+M on your keyboard.
- d. Press the F1 button on your keyboard.

6. Which of the following is not an available Unit Type to choose from?

- a. Scientific
- b. Metric
- c. Architectural
- d. Engineering

7. By default, which cardinal direction does the angle of zero point to?

- a. North
- b. South
- c. East
- d. West

8. Which of the following is not a method to remove an entity from the drawing?

- a. Click on the Erase icon in the ribbon, select the entity, and E then press Enter.
- b. Select the entity, then press the Delete key.
- c. Type the letter E, press the Spacebar, select the entity, and press the Spacebar again.
- d. Select the entity, then press <Ctrl>+Backspace on the keyboard.