progeCAD Training Course



Quiz Answer Key

Module M1-3

- 1. What happens when you configure Object Snap settings in the Drawing Settings dialog box?
 - d. They become available for selecting points as needed.
- 2. Which object types are compatible with the Center Object Snap?
 - d. Circles, arcs, and ellipses.
- 3. When can you use an Object Snap override from the context menu?
 - c. When a command is active and prompts for a point selection.
- 4. Accessing one or two reference points to locate a calculated point to use is known as what?
 - a. Object Snap Tracking
- 5. Snap and Grid cannot be enabled at the same time. If one is enabled, the other is disabled.
 - b. False
- 6. Which Status Bar settings must be enabled to use Object Snap Tracking?
 - b. Object Snap Tracking and Object Snap.
- 7. When using Object Snap Tracking, what appears at a reference point once it is acquired?
 - c. A green cross.